



SPECIALTY
PRODUCTS
GROUP

860GTS MICROBES™

FAST ACTING

DESCRIPTION

Already to use formula of stabilized natural occurring non-sporogenic bacteria. These microbes provide for maximum degradation of hydrocarbons, grease & oil. Microbes eliminate man made pollutants on the surface or below. GTS converts hydrocarbon pollutants into carbon dioxide and water.

BASIC USES

Grease trap and drain maintenance, reclaim pits in car and truck equipment washes, degradation of petroleum hydrocarbons and other organics. Superior odor control. Exceptional floor cleaners, excellent for stamping plant, machine shops, septic tanks for odor, ponds & lagoons. Marine bilge tanks, ground water & soil contamination.

GENERAL INFORMATION

Available in: 1 US gal bottle, 5 US gal pail, 55 US gal drum.

Coverage: varies from depending on job conditions.

Grease Traps: 20 oz/Day for regular maintenance.

Wash & Parts Tank: 1 US gallon for every 25 gallons of cleaning liquid.

Maintenance: 1 quart every week.

****Note:

FOG-Fatty Acids-Fat, Oil and Grease in water.

BOD-Biological Oxygen Demand is a measure of aerobic activity that takes oxygen out of water.

COD-Chemical Oxygen Demand is a measure of chemical activity that takes oxygen out of water.

GTS—Ground Trap Surface.

MAJOR ADVANTAGES

- Go to work immediately unlike conventional spore technology that requires 24 hour pre-germination to activate.
- Complete degradation resulting in no odor.
- Reduces, FOG, BOD, COD. ****NOTE
- Completely degrades hydrocarbons to carbon dioxide and water.
- Can significantly reduce costly clean up and removal.
- Remediating secondary containment areas.
- Doesn't harm plants or aquatic life.
- Can be sprayed on surface or injected.
- Stable in a wide range of pH from 4 to 11.
- Non Hazardous.
- No VOC's.
- Non-flammable.

SPECIFICATIONS

Appearance: Opaque to blue liquid

Bacteria Type: Stabilized Non Spore Microbes



SPECIALTY
PRODUCTS
GROUP

860GTS MICROBES™

FAST ACTING

SPECIFICATIONS CONTINUED

Bacteria Count: Guaranteed > 1.1 Billion Colony Forming Units (CFU) per US gallon at time of shipment.

Stability: There is no reduction in viability and activity for 12 months.

pH (as supplied): 6.5 - 7.5

pH (use conditions): 5 - 9.0

Temperature Range: 40°F-110°F (4°C-43°C)

Growth: Performs under aerobic and anoxic conditions

Specific Gravity @ 25°C: 1.0+0.02

Weight: 8.33 lbs/gal (1kg/L)

Salmonella free: Nonpathogenic

CLEANING CONTAMINATED CONCRETE FLOORS USING MICROBES

Cleaning contaminated floors has been a problem for the coatings industry forever. Detergents and caustics remove or disperse hydrocarbons from the surface of concrete, but do nothing for contaminants in the pores of the concrete. GTS Bacteria migrate into the pores of the concrete to totally digest oils converting them to carbon dioxide and water, eliminating adhesion problems for coating floors.

GTS will eliminate a number of contaminants, including Motor oil, Cutting oil, Hydraulic oil, Gasoline, Diesel and heating fuels, Fats (animal and vegetable), Grease, Solvents, Alcohols and sugars. Cleaning with bacteria leaves no residue, and can be coated as soon as the floor is dry enough per the coating manufacturer moisture recommendation.

It is important to remember that GTS is not an enzyme. They are not a detergent and do not disperse oil. They are living bacteria that eat hydrocarbons. They need the hydrocarbon food source to survive. Once their food source is gone, they die out. GTS does not leave any residue.

PROCEDURE FOR CLEANING CONCRETE FLOORS

Step 1 - Wet the floor and apply the microbes. Water serves two purposes. The microbes need a moist climate to work, and water aids the mobility of the GTS microbes, so they have the most opportunity to come into contact with hydrocarbons.

Step 2 - Agitate. Agitation helps disperse the microbes and helps break down the oil for faster digestion. Agitate the floor periodically and keep the floor moist while the bacteria are working. The time needed for cleaning will vary between 30 minutes to several hours, depending on how much contamination there is. Keep in mind that some floors have been exposed to oil for many years, and may need a few days for the microbes to completely digest all the contamination.



SPECIALTY
PRODUCTS
GROUP

860GTS MICROBES™ FAST ACTING

PROCEDURE FOR CLEANING CONCRETE FLOORS CONTINUED

Step 3- Rinsethefloor. Rinse todrain,orrinseandshopvac themicrobesfrom the floor. Dry the floor thoroughly and coat according to coating manufacturers recommendation (NOTE - microbes do not etch concrete).

Potential Problems: Be sure the pH of the floor falls into a range the microbes can survive in. Chlorine bleach kills the microbes. Do not use in conjunction with products containing chlorine.

WARRANTY DISCLAIMER

The information herein is to assist customers in determining whether our products are suitable for their application. Our products are intended for sale to industrial and commercial customers. We request that customers inspect and test our products before use and satisfy themselves as to the contents and suitability. We warrant that our products will meet our written specifications. Nothing herein shall constitute a warranty expressed or implied, including any warranty of merchantability or fitness, nor is protection from any loss or patent to be inferred. The exclusive remedy for all proven claims is replacement of our materials and in no event shall we be liable for special, incidental or consequential damages.



NPA

NATIONAL
POZZOLAN
ASSOCIATION

